



HO SCALE
FLEX PAVEMENT
949-1250 Series

Thanks for purchasing this SceneMaster kit. Please take a few minutes to read these instructions before starting. These preprinted roadways are ready to use with appropriate markings for modern or vintage scenes, and available in both straight and curved sections that are easily combined to model paved streets quickly and easily. For ease of assembly, you may wish to have these on hand before starting: see your local hobby dealer or visit walthers.com for the current selection. PLEASE NOTE: For best results, roads must be installed on clean, smooth surfaces such as bare wood, plastic, cardboard or foam: the roads will not adhere properly on irregular or rough surfaces covered with other scenery materials such as grass or gravel.

- 1) Determine where you'll install your roads - the material is easily cut with a sharp hobby knife if needed, and can be stretched into gentle curves for added realism.
- 2) Begin by carefully removing a few inches of the protective backing sheet from one end of the roadway. Lay this exposed end flat, and carefully press it in down on the layout surface.
- 3) Continue to remove the backing paper and position the road. As the material is flexible, make sure it lies smooth and is not stretched out too tightly. For slight bends or curves, remove a bit more backing paper at that location and gently stretch the edge, but avoid creases.
- 4) Make any final adjustments as needed, and press the entire road firmly into place.