


Thanks for purchasing this SceneMaster® kit. Please read and study these instructions before starting. Parts are included to build a large, medium and small reel, but can be arranged in various ways as shown. All parts are real wood; some warping may occur as your model acclimates to your layout room. Use compatible glue for wood to attach parts to each other.

PLEASE NOTE: Most of the cutting is already done, however each part is still attached to the frame. Use a new knife blade and carefully cut - do not twist or break parts loose - each attachment point.

1) Each reel has two ends of the same size, assembled with inside and outside surfaces as shown. Insert a straight pin (not included) through large center opening on a Reel End (1) with laser-engraved detail facing outward. Place the second end on the pin with the wood grain facing inward, align small openings and glue where parts meet.



2) Align center opening of Spacer (2) on pin and glue to Reel End. Align the remaining Reel End, and glue to Spacer.

